

INSTRUCTIONS FOR QUICK AND EASY APPLICATION FOR LONG TERM PROTECTION

VanGard has often been proven to be the quickest Vehicle Protection System to apply if you follow these simple procedures. New vehicles once de-waxed do not need to be polished/waxed prior to **VanGard** application.

Step 1 - Slippery Dipper (Polymer Paint Protection)

- 1 Shake bottles well before use.
 - 2 Apply Stage 1 to the vehicle providing an even coating with a soft cloth or pad.
 - 3 Let it haze allowing approximately 15 minutes and then apply Stage 2 directly over it with a soft cloth or pad.
 - 4 Allow 15 minutes for Stage 2 to cure then buff off with a soft, clean cloth to reveal the high gloss lustre.
ALLOW WHEELS CAN BE TREATED SIMILARLY.
-

Step 2 - Spill Dodger (Fabric Protection)

- 1 Spill Dodger is ready to use - do not dilute.
 - 2 Ensure that the upholstery and carpets are free from any shampoo or detergent residue.
 - 3 Spill Dodger can be applied to damp or dry fabrics and carpets after cleaning and rinsing.
 - 4 Apply evenly to the upholstery or carpets spraying in a north to south and east to west direction.
 - 5 Leave the carpets and upholstery to dry completely before use.
-

Step 3 - Roo Skin Shield (Leather Protection)

- 1 Lightly work into leather surface with a clean, dry microfibre cloth.
 - 2 Leave for one minute and wipe over with a dry, clean microfibre cloth to remove any excess.
 - 3 Place the part used Roo Skin Shield in your van for future treatments.
-

Step 4 - Ridgy Didge All-Purpose Protector (Vinyl Protection)

- 1 Shake bottles well before use.
 - 2 Apply to a soft cloth or pad.
 - 3 Wipe directly onto the vinyl surface.
 - 4 Leave for a minute and wipe over with a dry, clean microfibre cloth to remove any excess.
-

If you have any questions, you can reach us at
hello@vangard.com.au or 02 9052 4922

Watch the
video



WWW.VANGARD.COM.AU